


# Learning Tablet

**User Guide** 

## Contents \_\_\_\_\_

Unpack	p.1
Learning Tablet Layout	p.2
Charge the Battery	p.4
Setting the Device	p.4
Quick Setting Panel	p.4
Internet Control	p.6
Specification	p.7
Getting Started	p.7
Language Learning - Home screen	p.8
System Bar	p.8
Desktop	p <b>.</b> 9
All Applications	p <b>.</b> 9
Voice Translate	p.10
Talking Dictionaries. Oxford Dictionaries	p.12
Professional Dictionary	p.16
Look Up a Word	p.16
Textbooks	p.17
Braing Training	p.20
Start to Learn	p.23
Travel 100	p.25
Tests. Grammar. Vocabulary	p.26
Comet Phrasebook	p.28
Flash Cards	p.29
Touch to Speak	p.30
Audio Books	p.31
Troubleshooting	p.32

## **UNPACK**



<sup>\*\*</sup> If any of the items is missing, please contact your retailer.

<sup>\*\*</sup> The Screen Protector, Stylus Pen or Protective Case is purchased separately.

## **LEARNING TABLET LAYOUT**

### **POWER BUTTON ON/OFF**

Turn ON - Press and hold the power button for about 5 seconds until you see the display turning On.
Turn OFF - Press and hold the power button for about 2 seconds to display the shutdown dialog box, tap Power Off.

#### **VOLUME**

- 1]. Press the Volume key (+) to louder, (-) to lower.
- 2]. Show a slider on display to adjust the volume level.




### **TOUCH SCREEN PANEL**

- 1]. Tap a tile to start an application
- 2]. Using touch gesture, tap, drag or pinch etc.

#### **MSD CARD**

Insert a Micro SD Card into this slot. The Learning Tablet accepts memory cards with maximum capacities of 32GB.

METAL CASE of high durability



#### **AUDIO SPEAKER SYSTEM**


The Learning Tablet is equipped with a built-in high quality dual speakers.

Audio features are software controlled.

## **RESET --**


If your device experiences fatal errors, hanging, or freezing, you may need to reset the device to regain functionality.

**HDMI Port** 



#### **CAMERA**

- 1]. Selfie, picture taking or other interactive applications.
- 2]. Record Videos.



## **CHARGE THE BATTERY**

\*\* Before using the device for the first time or when the battery is low, you must charge the battery.


USB Charger

Fully charge the battery up to about 7 hours for first time use.

\*\* Use the USB Power adapter that comes with your device, connect your Learning Tablet to a power outlet.

The power plug of the adapter varies with your country of origin.

Input Voltage: 100V — 240VAC Output Voltage: 5.0V, 2.0A



- \*\* If the battery is completely discharged, you cannot turn on the device, even while it is charging. Allow the battery to charge for a few minutes before you try to turn on the device.
- \*\* When the battery is low, the device will emit a warning tone and show a low battery message. Recharge the battery to continue using your tablet.
- \*\* When you are not using your device, switch to Sleep Mode by pressing the Power key. This can help you to save battery power and can use the device longer between charges.

## **SETTING THE DEVICE**

There are several ways to enter the Settings screen, tap Settings Icon [ ] to display Settings Menu. Get more from your device by changing settings to match your preferences.

## **QUICK SETTING PANEL**

 Drag Down the notification area on the top right corner.

The Quick Setting Panel will pop up on the right, tap the individual icons to turn On/Off the function.



#### **OWNER**

-- This feature is not for your model.

#### **BRIGHTNESS**

-- Adjust the brightness of the display

## **SETTINGS**

-- Tap it to display Settings Menu

## Wi-Fi On/Off

- -- By default, your learning tablet activates the Wi-Fi feature.

  All the learning applications on the Language Learning screen does not need internet connection.
- -- You may tap on the Wi-Fi Icon to connect to a Wi-Fi AP and access the internet, to do other features required internet connection e.g. Browser, Youtube or Facebook etc.
- -- Please note: Turn on the Wi-Fi feature will consume more battery power.

### **EMERGENCY CALLS ONLY**

-- This feature is not for your model.

#### **AUTO ROTATE**

- -- By default, your learning tablet automatically changes its orientation from Landscape to Portrait mode and vice-versa depending on the way you hold your learning tablet.
- -- Please note: All the applications on Language Learning are designed with their orientation and they will not be changed even the auto-rotate function is activated.

#### **BATTERY STATUS**

-- View the amount of battery power consumed by your device.

#### **AIRPLANE MODE**

-- Activate AIRPLANE mode to disable all wireless functions on your device. You can use only non-network features.


## **BLUETOOTH On/Off**

-- Activate the Bluetooth feature to exchange information over short distances.

## **INTERNET CONTROL**

If the learning tablet is a present for kids and you don't want it to go internet, you may lock the internet feature of your device.

- \*\* Tap the icon of Internet Control ( a) on All Application.
- \*\* Set a password, and confirm.
- \*\* Select to lock the Internet Connection.



When you decide to release the device to go internet, you may unlock the Internet Connection.

## **SPECIFICATION**

ODU	O AO Dual 4 2017
CPU	Cortex-A9, Dual core, 1.2GHZ
Operation System	Android 4.2 Jelly Bean
System RAM	DDR3 1GB
Storage Device	Built in Nand Flash Memory Chip 32GB Support e ternal MSD up to 32GB
LCD	7" IPS 1280*800 high resolution Touch Screen
Battery	3.7V, 4000mAH, Li-polymer rechargeable battery
Camera	Front: 0.3 MEGA, Back: 2.0 MEGA
WIFI	802.11b/g/n
Bluetooth	V3.0
USB	Micro USB, USB 2.0 OTG
Micro SD	MSD card slot, support up to 32GB
Earphone	3.5mm stereo earphone
G-Sensor	3D Gra ity Sensor
HDMI	Support Mini HDMI, Output TV or Projector
Audio Format	MP3, WMA, MP2, OGG, AAC, M4A, MA4, FLAC, APE, 3GP, WAV, etc.
Photo Format	JPG, JPEG, GIF, BMP, PNG
Video Format	AVI ( H.264, DIVX, DIVX, XVID, rm;mvb, MKV ( H.264, DIVX, DIVX, XVID), WMV, MOV, MP4 ( H.264, MPEG, DIVX, XVID) , MPEG, MPG, FLV ( H.263 , H.264)
Ebook	PDF, TXT, CHM, DOC, EXCEL, EPUB, RTF, FB2, etc.
Power adapter	Input 100-240VAC, Output 5.0V===2.0A
Unit dimension	120 x 204 x 11.5 mm (WxDxH)
Weight	333 grams. Plastic and Metal Case.

## **GETTING STARTED**

## \*\* Turning the device ON

Press and hold the power button for about 5 seconds until you see the display turning On.

## \*\* Unlock the touch screen and the keys

When you turn on the device, the screen lock feature is activated to prevent unintended operations. Unlock the screen, drag your finger outside of the lock circle.




## Language Learning - HOME screen

## All language learning programs are built-in the tiles on this home page, NO internet connection needed.


\*\* Swipe up or down to see whole page







## \*\* Swipe Left or Right to next page







## Language Learning (Home)

All language learning programs are built-in the tiles on this home page, NO internet connection needed.

- \*Off-Line Voice Translate
- \*Talking Dictionaries
- \*Talking Text Translator
- \*Oxford Dictionaries
- \*Professional Dictionary
- \*Look Up a Word
- \*Textbooks
- \*Brain Training
- \*Start to Learn
- Otalit to Loai
- \*Travel 100
- \*Tests
- \*Grammar
- \*Vocabulary
- \*Phrasebook
- \*Flash card
- \*Touch to Speak
- \*Audio Books

## **Desktop**

This display screen lists those programs, icons or applications which you like to move, access, add to, put away or throw away from all applications in your tablet device.

- \* Built in all dictionaries on your desktop which you can select and browse each specific dictionary individually.
- \* Built in On-Line Voice
  Translate application ( ) \*
  for all languages. You may
  use On-Line Voice Translator \*
  to get more accurate
  recognition when you can
  access internet. If you don't
  have internet or don't want
  to use internet for this function
  you may go to the Off-Line Voice
  Translate on the Language
  Learning.

## **All Applications**

This display screen lists all applications program, data program or software program that runs on your tablet device.

Default applications of Android system.

- \* Gallery. Camera. Maps. Settings.
- \* Facebook. Youtube. Wikipedia. Browser
- \* Contacts. Email. Notes. Sound Recorder.
- \* Musics. Videos. Games. E-Books.
- \* Calculators. Calendar. Clock. Play Store
- \* Internet connection required for some applications such as Facebook. Youtube, Wikipedia or Browser etc.

## **VOICE TRANSLATE**




**VOICE TRANSLATE** let you translate what you say. No Internet connection needed.

## **Over 10 Speaking Languages:**

English. German. French. Spanish. Italian. Portuguese. Russian. Chinese. Japanese. Korean or Dutch.

Over 10 to 20 Translation Languages (according to the languages of your model)

\*\* Tap a tile to start an application



**Speak and Translate:** 

\* Tap microphone icon ( 💟 ) and speak your text.







- \* It display translation of your target language.
- \* Tap speaker icon ( ) to listen voice.



#### **Edit:**

The Voice recognition accuracy rates is about 70% in normal conditions.

Device vary widely in the ability to recognize voice due to noisy background or different accents.



In this case, you may need to edit your text.

\* Tap your text or ( ) icon to edit by keyboard.

## TALKING DICTIONARIES. OXFORD DICTIONARIES



From and to 20 Language Talking Dictionary and Text Translator.




## **Select Language:**

Tap ( □ ) to pull down the language list
 ( ➡ ) indicates two ways language translation, press it to reverse language.

#### **Enter Word or Phrase:**


\* Type word or phrase





## **Keyboard:**

- \* A keyboard is appeared which you can type with your input language.
- st Tap numeric icon ( 123 ) to switch the keyboard to type digits.
- \* Other keyboard will be displayed once you select it as the Input Language.
- \* Tap ( ) to hide the keyboard.




## **Dictionary List:**

There is large amount of built in dictionaries and you may select to see definition on other dictionaries.



### **Cross Search:**

\* Press and hold your finger over the word or text where you want to highlight to do Cross Search it on dictionary.




**1** Voice Matching:

Pronounce learning, for you to pronounce your own voice and compare how similar as the professional speaker.

- \* Tap VOICE MATCHING ( O MATCHING ) icon, record your voice. Play the voice of professional speaker to compare.
- 2 Save ( 3 save ): Tap this icon to save the word or text to Favorite List.
- 3 Favorite ( ★ FAVORITE ): View your Favorite List.

## **PROFESSIONAL DICTIONARY**

Built in professional dictionaries, type or scroll down to view all the contents.







## **LOOK UP A WORD**



The Dictionary function, unlike the Text Translator function, is a more direct way to quickly and easily look up single words at a time. It will automatically list other single words that are related to the word that is typed, but it will not list other phrases or sentences. This clear and direct word search method makes this function ideal for checking spelling.


## **TEXTBOOKS**

Study and Teaching Materials providing Full Audio, Touch to Speak and Voice Matching.

## Select a Textbook


- \*\* Collection of Textbooks.
- \*\* Tap to select the right Text Book you use.






## **Look Up**

\*\*Tap Chapter Contents Charts to the page you want to go or swipe left to start look up the book



#### **Listen Voice**



## **Cross Search Dictionary:**

\* Press and hold your finger over the word or text where you want to highlight to do Cross Search it on dictionary.



\* Once you have highlighted the correct area, a new box that give you the option to Cross Search will appear on top of screen.

## **Adjust the Speaking Rate:**


You can adjust the speaking rate, how fast or how slow it is reading out loud. You can choose to slow down the speedif you're studying and want to catch every details of the pronunciation.

\* Tap the Setting icon ( ) on the screen.

\* It shows a slider to adjust:

The Turtle icon indicates slower:

The Rabbit icon means faster.




## **BRAIN TRAINING**



Intelligent interactive learning games to learn languages, it is a fast and fun way to learn and remember over thousands of basic words and phrases.

- 1,200 words, phrases and pictures
- Speak aloud all languages
- Voice Matching
- Learn 20 languages:

\* Back to last screen.\* HOME to get back the home page.





\* Tap to select the language you learn.

## \* Tap to select category



\* Level I


\* Index to select Catagory




01:00 Level II, Clock to indicate the time you use.




\* Level III, ( ) to indicate the time you can use to remember the position of word.





## **START TO LEARN**



## Designed for beginners to learn foreign languages starting from the ABCs.

- Alphabets speaking and writing.
- Numbers, Clock, Days and Months.
- Learn 20 languages:

- \* Tap to select the language you learn.
- Start to Learn

  Chinese

  Learn

  Korean

  Learn

  Korean

  Learn

  Learn

  French


  Learn

  Japanese

  Learn


  Spanish

\* Tap to select the subject.




\* Number to Text Converter, type number to get English translation.






\* Tap the letter to see the related word or picture on slider.




A simple and perfect tool for travelers, executives, expatriates, multi-cultural living, backpacking, and getting in and out of trouble around the world.

- With 160 spoken phrases, displaying subjects on same screen to find phrases quickly and easily. Tap phrase and you immediate get the translation spoken aloud.
- -- 20 languages inter-translate:








## **TESTS. GRAMMAR. VOCABULARY**

The test evaluates your knowledge of language, work through practice questions at your own pace and see how well you know at your level.

The Grammar provides Irregular Verbs, Verb Conjugation and inflection to improve your language skills.





\*\* Tense List -

Tap to select tense or swipe down to see all contents



tap to listen voice

## **COMET PHRASEBOOK**




A collection contains 20 languages and total 66,000 phrases, displays all languages on full screen that provides you essential and professionally translated phrases, including audio. It is vital in helping you develop expressive and receptive language skills, master new phrase and strengthening comprehension in multi-languages.



## **FLASH CARD**

\*\* Tap or swipe left to start lookup



A learning drill to aid memorization.


Over 37 total essential sets, 1,500 vocabularies

With images and voice for learning or teaching
basic vocabulary for beginner of 20 languages.

\*\* Select native language and learning language







\*\* Tap Flip icon to see

word translation only.

\*\* Swipe left or right to next

to previous card.

card; or tap to see next,

\*\* Tap Speaker icon to have translation and voice.

29

## **TOUCH TO SPEAK**



Touch and speak a language book which contains over 2,000 essential phrases and words for life. The book is designed with a tile format to help you remember or find the word or phrase.

Listen to the pronunciation of the phrases you tap.

\*\* Index to search or skip to the subject or page number.

\*\* Tap the book you want to go.





\*\* Swipe left or right to next page.





\* Tap phrase to listen voice.

Collections of English Classic, English Lessons, English Animation and Poetry.









#### **TROUBLESHOOTING**

## 1. Lock or unlock the touch screen when Power On the device The touch screen responds slowly when Power On the device

When you Power On the device, it takes about a minute to load the contents on the device.

Your device may lock the touch screen to prevent unintended operations.

If the loading has not been completed, the device may not respond if you unlock it. You may press the Power key to activate the touch screen if you see the touch screen off.

## 2. The device has no respond while it is charging

If the battery is completely discharged, you cannot turn on the device, even while it is charging. Allow a depleted battery to charge for a few minutes before you try to turn on the device.

## 3. Don't know if the device is on charging

Press the Power Button, the screen displays a charging battery icon to indicate the device is on charging.

## 4. Don't know if the device is fully charged

Press the Power Button, the screen displays a fully charge battery icon to indicate the device is fully charged or still on charging.

### 5. The device beeps and the battery icon is empty

Your battery is low. Recharge the battery to continue using the device.

#### 6. Your device is hot if touched

When you use applications that require more power or use applications on your device for an extended period of time, your device may feel hot.

This is normal and should not affect your device's lifespan or performance.

### 7. The touch screen responds slowly

Your device freezes or has fatal errors

If the touch screen responds slowly, you may need to close applications with the task manager or reset the device to regain functionality.

## 8. Data usage -- The data size is less than the specification

The actual available capacity of the internal memory is less than the specified capacity because the operating system and default applications occupy part of the memory.

## 9. Accuracy of Voice Translator

The Voice Recognition accuracy rate is about 70% to 80% in normal conditions. Device vary widely in the ability to recognize voice due to noisy background or different accents. If you have met a small recognition missing or mistake, you may simply edit your voice text by tapping a keyboard on screen.

## 10. What's difference between the Voice Translator on Language Learning and the Voice Translator on Desk Top

- \*\* The Voice Translator on Language Learning is an OFFLINE application, no internet connection needed. The Offline Recognition accuracy rate is about 70% in normal conditions.
- \*\* The Voice Translator on Desk Top is an ONLINE application, it need Wi-Fi or 3G/4G internet connection. The Online Recognition accuracy rate is about 80% in normal conditions.

## 11. Accuracy of Computer Text Translator (no internet needed)

The Computer Text Translator is about 80% to 100% accuracy.

If the phrase you want to look up is not listed among the results, or the database does not include a phrase, then the computer will automatically generate a translation.

Since the translation is generated by computer, the result should be used as reference rather than exact translation.

If only a single word is entered, the product will automatically transfer to the Dictionary interface.

## 12. Where to find an individual dictionary to look up, e.g. Oxford Dictionary of English

All the dictionaries are built in the application of

[Talking Text Translator - Talking Dictionary]; or [Look up a Word].

If you want to look up an individual dictionary, you may find all the individual title of dictionary on Desk Top.

#### 13. Whether the device need Wi-Fi or Internet connection

It does not need internet connection if you don't use Browser, Youtube, Facebook, Wikipedia, Play Stores or other applications you download by yourself.

You need to activate Wi-Fi if you want to have Internet access for above similar features.

#### 14. Whether the device can go internet or cannot go internet

The device can go internet through Built-in Wi-Fi or connect with external 3G dongle. The device is default to have internet connection.

If you want to give the device to kids and do not want them to access internet, you may input password to lock the feature of Internet Connection on your device. When you want to have Internet Connection back, you may unlock the control. The application of 'Internet Control' is placed on the 'All Application'.

#### 15. How to use 3G connection because the device does not have built-in 3G function

You may purchase an external 3G dongle in a telecommunication company of your city, plug in the 3G dongle to the device.

### **16.** Whether all languages have Computer Text Translation

Most of languages have this technology built in except some languages of Myanmar, Sinhala, Tajik, Kyrgyz, Uzbek or Turkmen etc.